

ASSEMBLY INSTRUCTIONS

for 4' Chippendale and English Garden Bench & Chair

*(To view a picture of a fully assembled bench
see the website of your purchasing company.)*

1. Unpack kit, review hardware. It should include the following:

- (8) 1/4" x 3" hex lag bolts
- (14) 2 1/2" screws
- (2) 1 1/2" screws

Tools required

- 7/16" Socket or open end wrench
- #2 square bit *(included - works best with power drill)*
- Hammer

2. Hold both leg/arm sections upright.

Then place the back of seat section onto the metal brackets on the leg/arm assembly.

(Note: Be sure counter-sunk holes are to the outside of the arm/leg assembly.)

Line up the front part of the seat with mark on the front leg, and fasten each side with (2) 2 1/2" screws
Secure the metal brackets to the bottom of the seat with (2) 1 1/2" screws.

3. Place back section between the back uprights.

Align the hole on the back with the hole on the leg arm section, and fasten with (4) 1/4" x 3" hex lag bolts.

4. Put the brace piece without trim pieces in back, behind the seat.

Align the hole on the brace with hole on the back legs.

Fasten each side with (1) 1/4" x 3" hex lag bolt w/ washer.

Fasten center of brace to the back of the seat with (2) 2 1/2" screws.

5. Put the brace with the trim pieces *(curved 2x4)* in front of the seat, by lining up the holes on the brace with the holes on the front seat.

Fasten each side with (1) 1/4" x 3" hex lag bolt and washer.

Secure center of brace to the front of the seat with (2) 2 1/2" square screws.

6. Be sure all screws and nuts are tight and securely fastened.