

ASSEMBLY INSTRUCTIONS for wooden & poly fan-back chairs

*(To view a picture of a fully assembled bench
see the website of your purchasing company.)*

1. Unpack kit, review hardware. It should include the following:

- (4) 1/4" x 3 1/4" carriage bolts w/ nuts
- (2) 1/4" x 4" hex lag bolts
- (6) 1 1/2" screws

Tools required

7/16" Socket or open end wrench

#2 square bit *(included - works best with power drill)*

Hammer

2. Place seat upright on an even surface w/ slats on top.

Begin by putting back section against the last slat on seat and fasten with (6) 1 1/2" screws.

3. Fasten the arms and legs by putting (4) 1/4" x 3 1/4" carriage bolts into the pre-drilled hole in legs and seat. *(Do not secure tightly with nuts yet)*

4. Using (2) 1/4" x 4" lag bolts, fasten the arms to the back section, tighten securely. Now you can tighten the 1/4" nuts securely on the front legs.

6. Be sure all screws and nuts are tight and securely fastened.
Enjoy a nice sunset or sunrise with a refreshing drink.